



# Xcluder Pest Control Door Sweep Installation Instructions

Use for Part #: 162600, 162602, 162604, 162608, 162620, 160622, 160624, 160628, 162638, 162640,

## Installation Instructions: (Continued)

- Close door. Hold sweep at bottom of door. Tap down until contact is made between the sweep and the threshold.
- 6. Mark Screw Holes
- 7. Drill pilot hole for screws using a 7/64" (.278 cm) bit
- 8. Attach sweep with the included stainless steel mounting screws Adjust sweep position so sweep does not impede proper closing and latching of door.  
**IMPORTANT:** Make sure the door sweep makes even contact with the threshold or floor across its width