



Always wear gloves and eye protection when handling Xcluder.

1.



IDENTIFY IT

Identify gaps and spaces where rodents can enter or where there is evidence of pest activity.



Mice can fit through a 6-7mm gap.

Rats and rats can fit through a 20mm gap.

2.



MEASURE AND CUT

Wearing gloves, use scissors to cut a piece of Xcluder slightly larger than the opening.



3.



PLACE IT AND PACK IT

Place Xcluder into opening leaving no gaps or spaces. Carefully use screwdriver or other blunt tool to firmly press the material into the opening so that it is flush to or slightly below the surface.

